

## POC HOLDER INSTALLATION (ITEM# 970BK-PH)

### Step 1

Remove the storage bag from rollator by sliding it up and out of brackets. Remove the plastic caps on both the left and right sides (pictured). This is where the feet of the POC holder will be placed.

### Step 2

Place feet of holder into holes where caps were removed. Note the position of the holder. The feet of the holder are connected to arms which curve backwards towards the basket.



Place POC holder on rollator  
in this position.

